

Caller Line Identity

C.L.I-IS A FEATURE THAT ALLOWS YOU TO SEE THE INCOMING CALLERS NAME IF PROGAMMED.

WITH THE HANDSET ON THE HOOK

- 1 PRESS THE TRSF BUTTON
- 2 DIAL 200
- 3 DIAL 1234
- 4 DIAL 1
- 5 PRESS THE SPEAKER BUTTON
- 6 DIAL 728

YOU ARE NOW READY TO ENTER YOUR C.L.I

- 7 PRESS YOUR VOLUME + KEY TO FIND YOUR NEXT BLANK C.L.I BIN
- 8 PRESS YOUR RIGHT SOFT TOUCH KEY (THE THREE BUTTONS DIRECTLY BELOW THE SCREEN ARE CALLED THE SOFT TOUCH KEYS)
- 9 ENTER THE TELEPHONE NUMBER YOU DESIRE (IF YOU MAKE A MISTAKE PRESS THE HOLD KEY TO DELETE ALL THE NUMBER
- 10 PRESS YOUR RIGHT SOFT TOUCH KEY
- 11 ENTER THE NAME OF THE CONTACT BY USING THE KEYPAD AND VOLUME + FOR A SPACE BETWEEN WORDS, OR IF YOU NEED TO USE THE SAME BUTTON TWICE i.e A AND C (IF YOU MAKE A MISTAKE PRESS THE HOLD KEY TO DELETE THE NAME AND START AGAIN, THIS WILL NOT DELETE THE NUMBER)
- 12 PRESS THE TRSF BUTTON TO SAVE THE C.L.I AND EXIT **OR** PRESS YOUR RIGHT SOFT TOUCH AGAIN TO TAKE YOU BACK TO STEP 7